



Decorative Vinyl & Fabric Corp.

Spec Sheet:

Morbern - Celebration

<http://dvcfabric.com/vinyl/product/celebration/>

Collection: Morbern

Markets: Hospitality, Healthcare

Pattern Style: Geometric

View Specifications

Finished Width: 54 inches

Standard Weight: 32.25 +/- 1.5 ounces per linear yard

Nominal Total Thickness: 44 +/- 4.0 mils

Abrasion Resistance: No significant wear after 500,000 double rubs with #8 cotton duck using the Wyzenbeek test method.

Roll Length: 30 linear yards

Mildew + Bacteria (Staph) Resistant

Anti-static Slip Finish

Urine Stain Resistant

Sulfide Stain Resistant

Oil Resistant

Enhanced Bleach Resistance

View Flame Resistance

Manufactured to meet the following flammability* requirements:

FAA, FAR 25.853(a) + Appendix F Part 1(a)(l)(ii)

Fed Std 191A-5903.1 (CID-A-A2950A) (formerly CCC A-680a)

Port Authority of NY + NJ

CID A A-2950A • FMVSS-302 • California 117, Section E • BIFMA Class A • UFAC Class 1 • NFPA 260A

*This term and corresponding data refer to typical performance in the specific test indicated and should not be construed to imply the behavior of this or any other material under actual fire conditions.

View Care and Cleaning

In general, most common stains can be cleaned using warm, soapy water and clear water rinses. Moderate scrubbing with a medium bristle brush will help loosen soiling materials from the depressions of embossed surfaces. For more stubborn stains, use Formula 409* commercially available mild detergent† in accordance with the manufacturer's instructions.

Full strength rubbing alcohol or mineral spirits†† may be tried cautiously as a last resort on very stubborn stains, if the above suggestions do not work. Indiscriminate use of any solvent, or solvent containing cleaner, can severely damage or discolor vinyl.

Note: Detergent should never be used on a regular or repeated basis for normal cleaning. Morbern recommends repeated rinsing with clear water after any cleaning procedure.

When disinfecting with bleach, dilute with water up to a 9:1 ratio (10%).

Liberally apply diluted disinfectant using a sponge. Rinse with cold water several times. Wipe dry and repeat if necessary. Federal regulations require that guidelines on the bleach label need to be followed for antiseptic or antimicrobial purposes.

†When opening a new container, please test the cleaner in an inconspicuous area as cleaner manufacturers may change formula without notice.

Morbern cannot be responsible when unknown changes are made by the manufacturer of the cleaner to their formulations between our 6-month verification intervals

††Caution: Exercise care as these solvents are flammable. Use only small quantities of solvents and keep clear of any sources of ignition. Wear protective gloves and ensure cleaning takes place in a well ventilated area.