

Morbern - Mulberry

Roll Width: 54 inches

Roll Size: 30 yards

Weight: 32.25 + 1.5 oz per linear yard

Thickness: 44 + 4.0 mils

Abrasion Resistance: No significant wear after 500,000 double rubs with #8 cotton duck using the Wyzenbeek test method

Mildew + Bacteria (Staph) Resistant

Anti-static Slip Finish

Urine Stain Resistant

Sulfide Stain Resistant

Oil Resistant

Enhanced Bleach Resistance

Repeat: Horizontal 12.4 inches Vertical 11.6 inches

Manufactured to meet the following flammability* requirements:

California 117, Section E

UFAC Class 1

BIFMA Class A

NFPA 260A

FMVSS-302

FAA, FAR 25.853(a) + Appendix F Part 1(a)(I)(ii)

Fed Std 191A-5903.1 (CID-A-A2950A) (formerly CCC A-680a)

Port Authority of NY + NJ

CID A A-2950A

*This term and corresponding data refer to typical performance in the specific test indicated and should not be construed to imply the behavior of this or any other material under actual fire conditions.

In general, most common stains can be cleaned using warm, soapy water and clear water rinses. Moderate scrubbing with a medium bristle brush will help loosen soiling materials from the depressions of embossed surfaces. For more stubborn stains, use Formula 409 commercially available mild detergent* in accordance with the manufacturers instructions.

Full strength rubbing alcohol or mineral spirits** may be tried cautiously as a last resort on very stubborn stains, if the above suggestions do not work. Indiscriminate use of any solvent, or solvent containing cleaner, can severely damage or discolor vinyl.

Note: Detergent should never be used on a regular or repeated basis for normal cleaning. Morbern recommends repeated rinsing with clear water after any cleaning procedure.

When disinfecting with bleach, dilute with water up to a 9:1 ratio (10%). Liberally apply diluted disinfectant using a sponge. Rinse with cold water several times. Wipe dry and repeat if necessary. Federal regulations require that guidelines on the bleach label need to be followed for antiseptic or antimicrobial purposes.

*When opening a new container, please test the cleaner in an inconspicuous area as cleaner manufacturers may change formula without notice.

Morbern cannot be responsible when unknown changes are made by the manufacturer of the cleaner to their formulations between our 6-month verification intervals.

**Caution: Exercise care as these solvents are flammable. Use only small quantities of solvents and keep clear of any sources of ignition. Wear protective gloves and ensure cleaning takes place in a well ventilated area.