



DISTRIBUTORS OF LEATHER, VINYL, FABRIC & FOAM
4527 GLENWOOD ROAD • BROOKLYN, NY 11203
Phone: 718 941 3326 • Fax: 718 941 6115
Email: mark@dvcfabric.com

Nomad Specifications

Finished Width: 54 inches

Roll Size: 40 linear yards

Standard Weight: 32.25 +/- 3 oz per linear yard

Thickness: 40 +/- 4 mils

Abrasion resistance: No Significant wear after 500,000 double rubs with #8 cotton duck using the Wyzenbeek test method

Cold Crack: -25° F

1000 Hours WeatherOmeter

Flame Resistance

FMVSS-302

CA-TB 117-2013 (Section 1-Cover Fabric), Sect. E

BIFMA Class A

UFAC Class 1

NFPA 260

Care & Cleaning

To prevent buildup of dirt and contaminants, which may cause permanent staining, periodic cleaning is highly suggested. The frequency of cleaning is dependent upon the environmental conditions the material is subjected to. In general, most common stains can be cleaned using warm, soapy water and clear water rinses. Moderate scrubbing with a medium bristle brush will help loosen soiling materials from the depressions of embossed surfaces. For more stubborn stains, use Formula 409® commercially available cleaner in accordance with the manufacturer's instructions. Full strength rubbing alcohol or mineral spirits may be tried cautiously as a last resort on very stubborn stains, if the above suggestions do not work. Indiscriminate

use of any solvent or solvent containing cleaner, can severely damage or discolor vinyl. Always follow with a clear water rinse after cleaning with solvents. Note: Detergents should never be used on a regular or repeated basis for normal cleaning. Morbern recommends repeated rinsing with clear water after any cleaning procedure. Bleach cleanable: When disinfecting with bleach, dilute with water up to a 9:1 ratio (10%). Liberally apply diluted disinfectant using a sponge. Rinse with cold water several times. Wipe Dry and repeat if necessary. Federal regulations require that guidelines on the bleach label to be followed for antiseptic or antimicrobial purposes. The following disinfectant cleaners are approved for use on MorCare™ products: Asepticare TB II, Lysol Foaming, Birex, Precise (Caltech), Cavicide (Metyrex), Super Sani-Cloth PDI, Citrace (Caltech), Virex 256, Dispatch, Wex-cide, CaviWipes, Virox 5, Oxivir TB, and Oxivir Plus. When opening a new container, please test the cleaner in an inconspicuous area as cleaning manufacturers may change the formula without notice. Morbern cannot be responsible when unknown changes are made by the manufacturer of the cleaner to their formulations between our 6-month verification intervals. Caution: Exercise care as rubbing alcohol and mineral spirits are flammable. Use only small quantities of solvents and keep clear of any sources of ignition. Wear protective gloves and ensure cleaning takes place in a well ventilated area.